



IP-PAR 12



DMX SHEET



IP-PAR 12

Channel		Function	Description	Value
4 Ch	8 Ch			
	1	Dimmer	Dimmer adjustment	0 - 255
1	2	Red	Red adjustment	0 - 255
2	3	Green	Green adjustment	0 - 255
3	4	Blue	Blue adjustment	0 - 255
4	5	White	White adjustment	0 - 255
	6	Strobe	Strobe slow to fast	0 - 255
	7	Function choice	Color effects	0~50: CH1-CH7 Control. 51~100: Different Colors output (CH8 choose color) 101~150: Colors Jump Change. 151~200: Colors Gradate. 201~250: Colors Pulse Change. 251~255: Sound-Active
	8	Function speed	Speed control	Speed from slow to Fast (When the value of 7CH is 51-100 or 251-255, the function is color selection)

