



LEDWASH

12X40



DMX SHEET



LEDWASH

12X40

Channel		Function	Description	Value
16 Ch	21 Ch			
1	1	Pan	Pan Adjustment	0 - 255
2	2	Pan Fine	Pan Adjustment Fine	0 - 255
3	3	Tilt	Tilt Adjustment	0 - 255
4	4	Tilt Fine	Tilt Adjustment Fine	0 - 255
5	5	Pan / Tilt Speed	From fast to slow	0 - 255
6	6	Zoom	From small to big	0 - 255
7	7	Dimmer	From 0 to 100 %	0 - 255
	8	Dimmer Fine	Dimmer Fine	0 - 255
8	9	Strobe	No	0 - 3
			From slow to fast	4 - 203
			Random strobe	204 - 255
9	10	Red	From 0 to 100%	0 - 255
	11	Red Fine	Red Fine	0 - 255
10	12	Green	From 0 to 100%	0 - 255
	13	Green Fine	Green Fine	0 - 255
11	14	Blue	From 0 to 100%	0 - 255
	15	Blue Fine	Blue Fine	0 - 255
12	16	White	From 0 to 100%	0 - 255
	17	White Fine	White Fine	0 - 255
13	18	Dimming Model	Mode 1	0 - 49
			Mode 2	50 - 99
			Mode 3	100 - 149
			Mode 4	150 - 255
14	19	Color temperature	No	0 - 255
			Color Macros	16 - 195
			2800 K	196 - 200
			3200 K	201 - 205
			4000 K	206 - 210
			4500 K	211 - 215
			5000 K	216 - 220
			5600 K	221 - 225
			6500 K	226 - 230
			7000 K	231 - 235
			7500 K	236 - 240
8000 K	241 - 255			





LEDWASH

12X40

Channel		Function	Description	Value
16 Ch	21 Ch			
15	20	Macro Color	No	0 - 15
			Effect - 1	16 - 31
			Effect - 2	32 - 47
			16 Numbers 1 Effect	48 - 223
			Effect - 14	224 - 239
			Effect - 15	240 - 255
16	21	Reset	No	0 - 250
			Reset	250 - 255

