



TILTSTROBE

IP



DMX SHEET



TILTSTROBE

IP

Channel					Function	Description	Value
7 Ch	14 Ch	15 Ch	42 Ch	43 Ch			
1	1	1	1	1	Tilt	Pan Adjustment	0 - 255
	2	2	2	2	Tilt Fine	Pan Adjustment Fine	0 - 255
2	3	3	3	3	Strobe Dimmer	Tilt Adjustment	0 - 255
3	4	4	4	4	Strobe Mode	No Strobe	0 - 5
						Strobe Mode 1	6 - 42
						Strobe Mode 2	43 - 85
						Strobe Mode 3	86 - 128
						Strobe Mode 4	129 - 171
						Strobe Mode 5	172 - 214
						Strobe Mode 6	215 - 255
	5	5	5	5	Reserverd	From fast to slow	0 - 255
	6	6	6	6	Strobe Macro	No Macro	0 - 15
						Strobe Macro 1	16 - 57
						Strobe Macro 2	58 - 99
						Strobe Macro 3	100 - 141
						Strobe Macro 4	142 - 183
						Strobe Macro 5	184 - 225
						Strobe Macro 6	226 - 255
4	7	7	7	7	Plate Red	From 0 to 100 %	0 - 255
5	8	8	8	8	Plate Green	Dimmer Mode 1	0 - 49
6	9	9	9	9	Plate Blue	From narrow to wide	0 - 3
7	10	10	10	10	Plate Shutter	From 0 to 100%	0 - 255
	11	11	11	11	Plate Macro	From 0 to 100%	0 - 255
	12	12	12	12	Plate Macro Color	From 0 to 100%	0 - 255
	13	13	13	13	Plate Macro Speed	From 0 to 100%	0 - 255



	14				Reserved		
		14	14	14	Tilt Speed	From 0 to 100%	0 - 255
			15	15	Dimmer Strobe Pixel 1	From 0 to 100%	0 - 255
			16	16	Dimmer Strobe Pixel 2	From 0 to 100%	0 - 255
			17	17	Dimmer Strobe Pixel 3	From 0 to 100%	0 - 255
			18	18	Dimmer Strobe Pixel 4	From 0 to 100%	0 - 255

Channel					Function	Description	Value
7 Ch	14 Ch	15 Ch	42 Ch	43 Ch			
			19	19	Plate Pixel 1 Red	From 0 to 100%	0 - 255
			20	20	Plate Pixel 1 Green	From 0 to 100%	0 - 255
			21	21	Plate Pixel 1 Blue	From 0 to 100%	0 - 255
		
			40	40	Plate Pixel 8 Red	From 0 to 100%	0 - 255
			41	41	Plate Pixel 8 Green	From 0 to 100%	0 - 255
			42	42	Plate Pixel 8 Blue	From 0 to 100%	0 - 255
		15		43	Dimmer Speed	From 0 to 100%	0 - 255

